

Many Dewhurst lift products are made of **polycarbonate** (Using GE's **Lexan®** or Bayer's **Makrolon®**). Products currently using this type of material are:



Pushbuttons and Pushbutton indicators (Polycarbonate pressels)



Hidden legends (Polycarbonate pressels)







Digital Display Units (Polycarbonate windows)



Other plastic components (Lantern Arrows, Key switches etc.)

To avoid damage to plastic parts and ensure proper cleaning of products caused by aggressive cleaning agents, Dewhurst recommends the following the instructions:

	Clean the part with cotton cloth and warm water before applying the cleaning product
	Use PH-neutral or slightly acid cleaning products only (including aromatised ones) Ethylic alcohol, isopropyl alcohol or ethylene glycol based multipurpose cleaning products and dish soaps are suggested
	Dilute the cleaning product in warm water and apply using a wet cotton cloth
	Grease, glue and paint may be removed with ethylic alcohol or isopropyl alcohol after the part



Warnings:

- DO NOT** use abrasive cleaning agents
- DO NOT** use sharp tools to remove dirt (chewing gum, glue, etc.)
- DO NOT** use solvents based with Ketones, benzene, methanol, toluene (also known as methylbenzene or phenyl methane) or alkaline and ammonia based cleaning agents
- DO NOT** use cleaning agents at high temperatures
- DO NOT** leave cleaning agents on the parts for long periods: remove immediately after cleaning using wet cotton cloth and warm water
- DO NOT** use dry cotton cloths and sponges



Recommended Cleaning Products (*):

Europe	North America
Windus - Brial Top - Ecolab	Formula 409® Cleaner Degreaser
Mr Proper Surfaces Delicates - Proctor & Gamble	Joy®, Proctor & Gamble
	Windex, Drackett Products
Palmolive, Colgate Palmolive	Palmolive, Colgate Palmolive

(* Due to the vast number of cleaning products available on the market, the list of recommended products above is illustration only